



1. SUBSTRATE PREPARATION

The existing floor tiles must be sound and well secured to the substrate. Any loose, broken or drummy tiles should be removed and the void filled with:



ARDEX A45

Rapid Hardening & Drying Repair Mortar for internal repairs and dormant cracks

The surface is to be cleaned and then mechanically prepared to provide a clean 'keyed' surface. Mechanical preparation is advised for the floor levelling products but is not required if Feather Finish is to be used.

Prime ceramic tile/terrazzo with:





ARDEX P9

Single Part Primer for Smooth and Dense Surfaces

OR

ARDEX P82

Two Component Synthetic Resin-Based Primer

Make sure that excess primer does not accumulate in the tile grout lines. ARDEX P9 is to be diluted 1:1.

2. INSTALL SMOOTHING/SELF LEVELLING



The levellers are to be applied between 3 and 4mm thick.

ARDEX FINE FINISH

Rapid drying smoothing compound

ARDEX FEATHER FINISH

Super high quality rapid drying smoothing compound

ARDEX K120

Quick drying levelling compound

ARDEX K220

Quick drying levelling compound

ARDEX K12 NEW

High quality levelling compound

ARDEX K10 REACTIV8

Reactivatable levelling compound

ARDEX K15

Very high quality rapid drying levelling compound

ARDEX K55

Ultra-rapid drying levelling compound

ARDEX ARDITEX NA

Flexible levelling compound

3. ADHESIVE FIX VINYL







MJS MAX BOND 2012

Vinyl plank adhesive

OR

MJS MAX BOND 4000

Universal adhesive

OR

ARDEX AF 180 MS

Heavy duty adhesive for areas with direct sunlight and moisture



